

## Replacement Remote Programming Procedure

Replacer for AVIDSEN 114253 104250 104251 104250 OLD 104250 RED 104257 104350 654250 114235

### English

The replacement remote control is a rolling code model that must be memorized on the receiver. For more detailed information, refer to the instructions of the remote control or gate control unit.

- 1) Open the box of the control unit or receiver and press the registration key located on the card, which according to the model can be called: ENR, MEMO, PROG, REC, RX, RF.
- 2) The led on the board will start flashing;
- 3) Press and hold the button on the new remote control for one second;
- 4) Release the button, the led on the board will turn off. The new remote control is memorized.

### Français

La télécommande est un modèle à code tournant qui doit être mémorisé sur le récepteur. Pour plus d'informations, reportez-vous aux instructions de la télécommande ou de l'unité de commande de portail.

- 1) Ouvrez le coffret de la centrale ou du récepteur et appuyez sur le bouton d'enregistrement situé sur la carte, qui selon le modèle peut être appelé: ENR, MEMO, PROG, REC, RX, RF.
- 2) La led sur la carte commencera à clignoter;
- 3) Appuyez et maintenez le bouton de la nouvelle télécommande pendant une seconde;
- 4) Relâchez le bouton, la led sur la carte s'éteint. La nouvelle télécommande est mémorisée.



**LA-TELECOMMANDE.FR**