







Télécommandes compatibles avec les télécommandes copieuses à code fixe en 433mhz et avec les télécommandes copieuses longue portée en 433mhz. Et avec les télécommandes copieuses de codes fixes multifréquence de 224 à 868mhz, ou de 280 à 868mhz.

<i>Marque</i>	<i>Fréquence</i>	<i>Modèles</i>	<i>Photo</i>	<i>Copieuses:</i>
ADYX	433.920	ALIZE EM2C, ALIZE EM4C		433 et Multi
AETERNA	433.920	TX433 1,2,4 buttons		433 et Multi
ALLMATIC	306.000	ASMX2, ASMX4		Multi
	433.920	AEMX1, AEMX2, AEMX4		433 et Multi
		EUROPE AUTO ARMY1, ARMY2, ARMY4		433 et Multi
		MX1, MX2, MX4		433 et Multi
ALLISTER	318.000	9931-318, 9931T-318		Multi
ALLSTAR	288.000	111025 Allister Pulsar Quickcode		Multi
		9921T-288, 9921MT, 9921TK, 9922T-288, 9923T-288, 9931-288, 9931T-288, 9931MT, 9931TK, 9931TK6, 8831T-288, 8832T-288, 8833T-288, 8821T-288, 8822T-288, 8823T-288, 8832TK		Multi
		8833OCS-288		Multi
	318.000	9921T-318, 9921MT, 9921TK, 9922T-318, 9923T-318, 9931-318, 9931T-318, 9931MT, 9931TK, 9931TK6, 8831T-318, 8832T-318, 8833T-318, 8821T-318, 8822T-318, 8823T-318, 8832TK		Multi
		110995 Allister Pulsar Quickcode		Multi
		8830OCS-318		Multi
ALLTRONIK	433.920	S429_1, S429_2, S429_4, S429_M Be sure that your remote operates at 433.92MHz!	 	Multi Rev.3, Four Rev.3
		S425		433 et Multi
ANSONIC	433.920	SA 434-1E, SA434-2E, SA434-3E, SA434-4E		433 et Multi

		SA 434-1MINI, SA434-2MINI, SA 434-2Midi		433 et Multi
	868.350	SA 868-1E, SA 868-2E, SA868-3E, SA868-4E		Multi
		SA 868-1mini/M, SA 868-2mini/M (dip switch version)		Multi
APERTO	433.920	CPS1, CPS2, CPS4		433 et Multi
APRIMATIC	305.000	TS1, TS2		Multi
AUTELCO	286-306	TX300T		Multi
AVIDSEN	433.920	100601 micromark MM23164		433 et Multi
		104505		433 et Multi
		100951, 100955, 100550, 100400		433 et Multi
B&D BnD BD	433.920	062170/4333EBD, 062171, 4333A		433 et Multi
		062162		433 et Multi
		PTX4 059120 / 059116		433 et Multi
BANDY	433.920			433 et Multi
BELFOX	433.920	DHS433-1, DHS433-2, DHS433-4, dip switch version		433 et Multi
		DHS 433,92 (7733), dip switch version		433 et Multi
	868.350	DHS 868,3, dipswitch version		Multi
		HS 868-20		Multi
BENINCA'	306.000	LOT1A, LOT2A, LOT4A		Multi
		LOTX1A, LOTX2A, LOTX4A		Multi
		LO.TX2PS		Multi
	433.920	LOT1W, LOT2W, LOT4W		433 et Multi


		LOT2WMS		433 et Multi
		T2WK, T4WK		433 et Multi
		LOTX1W, LOTX2W, LOTX4W		433 et Multi
		TO.GO2WP, TO.GO4WP, TO.GO2WK, TO.GO4WK		433 et Multi
BERNER	868.300	Berner BHS140		433 et Multi
		Berner BHS130		433 et Multi
BESIDE	433.920	BEZAP		433 et Multi
		HIT		433 et Multi
BETA ELETTRONICA	315.000	BETALARM 6500		Multi
	330.000	BETALARM 5500		Multi
BFT	306.000	RCS		Multi
	315.000	VTM1, VTM2, VTM4		Multi
	418.000	GT01, GT02, GT04		Multi
	433.920	TE01, TE02 (TEO1, TEO2)		433 et Multi
		TE04 (TEO4)		433 et Multi
		MITTO 2, MITTO 4: Only if the receiver is CLONIX 1 or CLONIX 2 with DIP2 in ON position		433 et Multi
BREDA	433.920	Breda TOP432SA	Like CAME TOP432SA, blue	433 et Multi
CAME	315.000	Came T312M, T314M		Multi
		Came TOP312, TOP314		Multi
		Came TOP432NA, TOP434NA		Multi
	433.920	Came T432, T434, TOP432A, TOP434A, TOP432, TOP432NA,		433 et Multi

		TOP434NA, TAM432, TAM434, TAM438		
		Came TOP432M, TOP434M		433 et Multi
		Came TAM432SA		433 et Multi
		Came TOP432SA		433 et Multi
		Came TOP432NA, TOP434NA		433 et Multi
		Came TWIN2, TWIN4		433 et Multi
		CAME TOP-432EV, TOP-434EV		433 et Multi
	868.350	CAME TOP862NA, Came TOP864NA		Multi
CARDIN	300.000	S300		Multi
	310.000	S301, S302		Multi
	433.920	S476 TX2, S476TX4		433 et Multi
CARPER	300.000 310.000 318.000	C300, C310, C318, C318T		Multi
CASALI GENIUS	330.000			Multi
	433.920	Genius 433 2, Genius 433 3, JA400 TM433, JA401 TM433		433 et Multi
CASIT	306.000	ERTS92B, ERTS92T		Multi
	433.920	ERTS92B, ERTS92T		433 et Multi
		ERTS20DB, ERTS20DQ		433 et Multi
		ERTS476D, ERTS476Q		433 et Multi
		TXS1, TXS2, TXS3, TXS4, TXS6 ERTS97B, ERTS97T		433 et Multi
CEDAMATIC	305.000	Cedamatic CTX1S, CTX2S, CTX4S		Multi
	433.920	Cedamatic AEMX1, AEMX2, AEMX4		433 et Multi
CELINSA	433.920	S10 1, S10 2, SAW1, SAW2		433 et Multi

CENTURION	433.920	CLASSIC, SMART, SMART2		433 et Multi
CHAMBERLAIN LIFTMASTER MOTORLIFT SEARS CRAFTSMAN	300.000	Chamberlain 300MC (multicode)		Multi
	315.000	333LM		Multi
		360LM, 362LM, 363LM		Multi
	390.000	50CB, 53CB, 750CB, 753CB, 50LM, 53LM, 61LM, 62LM, 63LM, 139.53100, 139.53110, 139.53200, 139.53210		Multi
		54CB, 756CB, 54LM, 64LM, 859CB		Multi
		850CB, 853CB, 959CB, 81LM, 82LM, 83LM, 84LM, 99LM		Multi
		33LM		Multi
	418.000	4180, 4182, 4183		Multi
		4185		Multi
		787 remote keyless entry		Multi
	433.920	4330E, 4332E, 4333E		433 et Multi
		4335E		433 et Multi
COSTEL	300.000	Minitix		Multi
CPS	433.920	TCP3, CPS, Jolly 4		433 et Multi
		CPS1 TCP3, CPS2 TCP3, CPS4 TCP3 EM1CV, EM2CV, EM4CV		433 et Multi
DASPI	433.920	Daspi Happy2 433, Daspi Pops2		433 et Multi
		Daspi Zero2, Zero2CLO, Zero4CLO		433 et Multi
DEA	306.000	306 1, 306 2, 306 4		Multi
		306		Multi




	433.920	433 1, 433 2, 433 4, Gold S1, Gold S2 Dea Gold 238 S1, Dea Gold 238 S2, Dea Gold 239 S4		433 et Multi
		Genie		433 et Multi
		Punto S2		433 et Multi
		Dea MIO TD2, MIO TD4		433 et Multi
DELMA	300.000	Apollo 300, ELSAMEC Apollo 300		Multi
		Mizard 300 1, Mizard 300 2, King		Multi
	433.920	Mizard 433 1, Mizard 433 2		433 et Multi
		King 433 2		433 et Multi
		Style Copy 2CH (this is a code duplicator)		433 et Multi
DICKERT	433.920	Dickert MAHS433 01, MAHS433 04 Note: we can NOT guarantee that it can be duplicated, because it depends by the receiver.		433 et Multi
		Dickert S10-433A1L00, S10-433A4L00, S20-433A1L00, S20-433A4L00, S20-433A1000, S20-433A4000 Note: only RED buttons model can be duplicated!		433 et Multi
		Dickert S5-433-A2L00, S5U-433-A2L00 Note: only RED buttons model can be duplicated!		433 et Multi
	868.350	Dickert HS868-21 Note: only RED buttons model can be duplicated!		Multi
		Dickert S5-868A2L00, S5U-868A2L00 Note: only RED buttons model can be duplicated!		Multi
		Dickert S10-868A100, S10-868A400, S20-868A1L00, S20-868A4L00, S20-868A1000, S20-		Multi

		868A4000 Note: only RED buttons model can be duplicated!		
		Dickert S5-868A2L01, S10-868A1L01, S10-868-A4L06, green buttons		Multi
DIGICODE	300.000 310.000	DC5010, DC5012, DC5030, DC5032, DC5040, DC5042, DC5060, DC5062, DC5070, DC5072		Multi
		GOL4C		433 et Multi
DITEC	433.920	GOL4 Note: These transmitters are rolling code and cannot be duplicated, but if you have a GOL4C device, you can duplicate it on Four or Multi, and it works with all the DITEC receivers.		433 et Multi
		BIX LS2, BIX LP2, BIX LG4 Note: These transmitters are rolling code and cannot be duplicated, but if you have a GOL4C device, you can duplicate it on Four or Multi, and it works with all the DITEC receivers.		433 et Multi
DOITRAND FDOITRAND	433.920	MPSTF2E JAUNE, MPSTF4E, HYPERPHONE MPSTF2E_GRISE		433 et Multi
		TS2DE, TS4DE		433 et Multi
DOORHAN	433.920			433 et Multi
DOORMATIC	433.920	SAW		433 et Multi
DUCATI ALLDUCKS	433.920	TSAW1, TSAW2, TSAW3, TSAW4, 124 ELBER TSAW1, TSAW2, TSAW3, TSAW4 RONDY TSAW1, RONDY TSAW2, RONDY TSAW3		433 et Multi
		TPR10-A, TPR20-A RONDY TPR10_A, RONDY TPR20_A		433 et Multi
		TE2		433 et Multi


		HC6203, 6203: only blue with transparent buttons, and transparent with transparent buttons		433 et Multi
ECP	292.000	FIX 292 MHz F105611		Multi
		KEY 292 MHz F106038		Multi
ELBE	433.920	501, 502, 504		433 et Multi
		502a, 504a		433 et Multi
		502, 504		433 et Multi
ELCA	300.000	Aster 1100, Aster 1101		Multi
	433.920	IRIS, IRIS 9CH. Model 433D only! Both colors red and blue		433 et Multi
		ASTER2		433 et Multi
		Aster 1000, Aster1001. Model 433D only! Colors: black, blue, light grey		433 et Multi
		GEMINI 9CH		433 et Multi
		VIRGO		433 et Multi
ELDAT MFZ	433.920	Eldat Basewave RT20-4103M-01, RT20-4104M-01, RT35-4104M-01, RT21-4101M-01, RT21-4102M-01, MFZ 400033		433 et Multi
		Eldat Basewave RT28-4101M-01, RT27-4101M-01, RT26-4101M-02, RT21-4125M-01, RT21-4139M-01, RT21-4139M-02, RT31-4139M-01, RT31-4139M-02, RTC02-4104M-01		433 et Multi
	868.300	Eldat Basewave RT20-5004M-01, RT20-5003M-01, RT35-5004M-01, RT21-5001M-01, RT21-5002M-01		Multi
		Eldat Basewave RT28-5001M-01, RT27-5001M-01, RT26-5001M-02, RT21-5025M-01, RT21-5039M-01, RT21-5039M-02, RT31-5039M-01, RT31-5039M-02, RTC02-5004M-01		Multi



ELEK	300.000	KTM194B		Multi
		KTR4		Multi
ELV CONRAD	868.350	FS20 S4, FS20 S8, FS20 S8-2, FS20 S16, FS20S16R, FS20 S20-2, FS20 S20-3		Multi
ELVOX	433.920	Elvox ET		433 et Multi
		Elvox ET03, ET04		433 et Multi
	868.350	Elvox ET08		Multi
EMFA	287.000	ET1, ET2, ET3		Multi
	308.000	ES_1, ES_2		Multi
ERONE	433.920	SETDS39433E2, SETDS39433E4		433 et Multi
ERREKA	289.000	Erreka E20, Erreka E22		Multi
	433.920	Erreka Luna, Erreka SMAT 1 RESON 1, RESON 2, RESON 3		433 et Multi
EUROPE AUTOMATISMES	306.000	ASMY1, ASMY2, ASMY4		Multi
	433.920	ARMY1, ARMY2, ARMY4		433 et Multi
		S1, S2, S3		433 et Multi
FAAC	300.000	TM300S, TM300S05 H Faac TM1 300, TM2 300, TM3 300		Multi
	315.000	T1, T2, T3 Faac TM1 315, TM2 315, TM3 315		Multi
	330.000	TM1, TM2, TM3 Faac TM1 330, TM2 330, TM3 330		Multi
	418.000	TM1 418 DS, TM2 418 DS, TM3 418 DS		Multi
		TM 418SL, TM1 418SL, TM2 418 SL, TM3 418SL		Multi



	433.920	TM1 433 DS, TM2 433 DS, TM3 433 DS TM1 433DS DPH, TM2 433DS DPH, TM3 433DS DPH		433 et Multi
		TML2 433 SLR, TML4 433 SLR, TML2-433-SLR, TML4-433-SLR, TML2 433 ESL, TML4 433 ESL		433 et Multi
		TML2 433 SLP, TML4 433 SLP, TML2-433-SLP, TML4-433-SLP		433 et Multi
	868.350	TM1 868 DS, TM2 868 DS, TM3 868 DS TM1 868DS DPH, TM2 868DS DPH, TM3 868DS DPH		Multi
FADINI BPT	315.000	ASTRO75-1, ASTRO75-2, ASTRO75-4		Multi
	433.920	433 2M, Astro43_2m		433 et Multi
		Astro433-2, Astro433-4, Astro43-2, Astro43-4		433 et Multi
FERPORT	433.920	Tac1, Tac2, Tac4, Tac1k, Tac2k, Tac4k, Tac2kr		433 et Multi
FORSA	287.000	Forsa Trieme		Multi
FUNKMODUL ELSECO	433.920	T433A2K1, T433A2K2		433 et Multi
		T433A2K4, T433A2K4n		433 et Multi
GIBIDI	306.000	TS2M		Multi
	433.920	Open TMB 433, OPEN TMQ 433, OPEN OUT 2, OPEN OUT 4		433 et Multi
GOBBATO	306.000	T306		Multi
GRIFFON	403.55	Griffon 404 MHz dip switch remotes and duplicating remotes		Multi
	433.92	Griffon 433 MHz dip switch remotes and duplicating remotes		433 et Multi
GTO	318.000	GTO Mighty Mule 1/2 buttons, RB741, RB742		Multi
		GTO Mighty Mule 3 buttons, RB743		Multi




GULLIVER	306.000	MDRQ 306		Multi
	433.920	MDW 2E		433 et Multi
HAUSS	433.920	Pocket 3750-1, Pocket3750-2, Pocket 3750-4		433 et Multi
HEDDOF	318.000	P219-1, P219-2		Multi
		P220-1, P220-2, P220-3		Multi
HORMANN HOERMANN	433.920	HSM2, HSM4, yellow buttons Please note that, in Netherlands, Hoermann sell this kind of remote control which transmit a rolling code: in this case it cannot be duplicated!		433 et Multi
	868.300	HS1, HS2, HS4, blue buttons		Multi
		HSD2		Multi
		HSE2, HSE4, blue buttons		Multi
		HSM2, HSM4, blue buttons		Multi
		HSP4, blue buttons		Multi
		HSS2, HSS4, blue buttons		Multi
		HSZ1-868, HSZ2-868		Multi
HRC	433.920			433 et Multi
JAY	433.920	UBEI x1 SL1		433 et Multi
		UBET 11, UBET 21, UBET 31, UBET 41, UBET 61Ã,		433 et Multi
JCM	290.000	EC1, EC2, EC3, ET1, ET2, ET3		Multi




KEY AUTOMATION	433.920	900TXB-42, 900TXB-42N, 900TXP-42, 900TXP-42N		433 et Multi
		900TXB-44, 900TXG-44		433 et Multi
		900SUB-44, 900SUB-44N, 900SUB-44W, 900SUB-44WN		433 et Multi
		900TXK-42, 900TXW-42, 900TXK-44, 900TXW-44		433 et Multi
KING	433.920	Note: receiver should be setup withrolling code feature disabled		433 et Multi
LABEL IUPPITER	306.000	MDR, IUPPITER 306		Multi
	433.920	RJW/1E, RJW/2E, RJW/4E, RJW/12E		433 et Multi
		MDW/1E, MDW/2E		433 et Multi
LEB	306.000	TSA4		Multi
	433.920	TMW		433 et Multi
		TSAW2N, TSAW4N		433 et Multi
		TCP3Ã, (this is a code duplicator)		433 et Multi
		TRK4 Note: receiver should be configured to disable rolling check.		433 et Multi
		TPW4		433 et Multi
	868.300	TPK4		Multi
LINCE	302.000	LE TX1, LE TX2		Multi
	433.920	LR 2035		433 et Multi
LINEAR	300.000 310.000	MULTI-CODE 308911, 308913, 1089		Multi
		MULTI-CODE 412001, 414001, 109410, 109710		Multi
		MULTICODE 306010, 307010, 108210		Multi


		MULTI-CODE 308301, 308302		Multi
		MULTI-CODE 105015		Multi
	310.000	Delta3 Moore-o-Matic: DT, DT2, DT2A, DT22A, DTC, DTD		Multi
		Delta 3 Moore-o-Matic: DT3, DT4		Multi
		Delta 3 Moore-o-Matic: Mini-T LB "LadyBug"		Multi
	312.000	Delta3 DTK (canada)		Multi
MA SYSTEM	433.920	MA TX1, MA TX2, MA TX3		433 et Multi
MARANTEC	418.000	D212, D222, D232		Multi
	433.920	D101		433 et Multi
		D12		433 et Multi
		D212, D222, D232		433 et Multi
		Digital 302, D302		433 et Multi
		Digital 304, D304		433 et Multi
	868.300	Digital 302, D302		433 et Multi
		Digital 304, D304		433 et Multi
MCZ	433.920	Aster		433 et Multi
MEIßNER MEISSNER	433.920	LW433-1, LW433-2, LW433-4		433 et Multi
		Pocket 3750 1, 2, 4		433 et Multi
MKTECHNO MK-TECHNO	306.000	MK-TECHNO TX1 and MKTECHNO TX2 with RED LED		Multi
MONSEIGNEUR	433.920	ARC2, ARC4		433 et Multi



		TDR 400 3845, TDR 400 3846, TDR 400 3847 T1SAW433, T2SAW433, T4SAW433		433 et Multi
MOTORLINE STATEUROP	433.920	MX1, MX2, MX3, MX4, MX6 MX11, MX12, MX13		433 et Multi
MOTOSTAR	433.920	CLIKSTAR2, CLICKSTAR4 CLICK-4M, CLICKSTAR RE 532, CLICKSTAR RE 534		433 et Multi
NICE	306.000	EASY S1, S2, S4		Multi
	433.920	FLO1, FLO2, FLO4		433 et Multi
		VERY VE		433 et Multi
NOLOGO	306.000			Multi
	433.920	ECO DIP		433 et Multi
NOVOTECNICA	306.000	BIT N1, BIT N2		Multi
		BIT NT1, BIT NT2, BIT NT4		Multi
OG	433.920	OG62, OG64		433 et Multi
O&O OeO, OandO,OetO	306.000	OeO TX2, TX4 (green buttons)		Multi
	433.920	OeO TX4-E, TX2-E (red buttons)		433 et Multi
		OeO T-COM DS 4-2, O&O T-COM DS 4-4		433 et Multi
OPENOUT	306.000	TS2M		Multi
	433.920	TMQ 433 2, TMQ 433 4		433 et Multi
PIAZZETTA	433.920	4 buttons for wood/pellet heater		433 et Multi
PORTAMATIC	433.920	MPH01, MPH02		433 et Multi

POWERFIX Profi (Lidl)	433.920	RCB-A 3600R		433 et Multi
PRASTEL	306.000	NCSMT1, NCSMT2P, NCSMT4P		Multi
		KMFT2P, KMFT4P, KMFT2P93, KMFT4P93		Multi
	433.920	MPSTF2E, MPSTF4E		433 et Multi
PROEM	433.920	ER2C4ACM, ER4C4ACM		433 et Multi
PROGET	433.920	ETY_433N2, ETY 433N4		33 et Multi
		EMI433-N2		433 et Multi
PROTECO	433.920	TX433		433 et Multi
		EUROMATIC		433 et Multi
		HIT		433 et Multi
PUJOL	288.000	JCM TRINARIO 1, TRINARIO 2, TRINARIO 3		Multi
	288.000	TT1, TT2, TRINARIO 1, TRINARIO 2		Multi
PULSAR	318.000	9931-318, 9931T-318		Multi
QUASAR	287.000	Tx SA4, Serie Argento, SA		Multi
	287.000	TXSA2T		Multi
	306.000	300 2, 300 4		Multi
	433.920	433 TANGO SLIM BLEU		433 et Multi
QUICK	433.92	Model: 302		Multi
RADIODIGIT	291.000	TBM, TCM		Multi
ROGER	433.920	R80/TX12, R80/TX14, R80/TX12R, R80/TX14R		433 et Multi

		H80/TX22		
		G80/TX32, G80/TX34, G80/TX32R, G80/TX34R		
SEA	433.920			433 et Multi
		SMART433_TX2_DIP, SMART433_TX3_DIP SMART433_TX2_COPY,SMART433_TX3_COPY Smart2 Dip Switch, Smart3 Dip Switch		433 et Multi
	868.350	231103, SEA868_4		Multi
		231103, Head2 Dip Switch		Multi
		SMART868-TX2-DIP, SMART868-TX3-DIP Smart2 Dip Switch, Smart3 Dip Switch		Multi
SEAV	306/330	TX1, TX2, TX3, TX4, TX1/330 TX2/330, TX3/330, TX4/330		Multi
	433.920	TXS1, TXS2, TXS3, TXS4		433 et Multi
		Behappy S1, Behappy S2, Behappy S3		433 et Multi
		Be Easy TX, Be Easy Murale2		433 et Multi
		BeSmart S2, BeSmart S4		433 et Multi
		BeFree S1		433 et Multi
	868.300	BeSmart H2, BeSmart H4		Multi
		BeFree H1		Multi
SECURVERA	433.920	SV R2C		433 et Multi
		SV R2C		433 et Multi
		SV R4C		433 et Multi
		SV R6C		433 et Multi

SENDER	433.920			433 et Multi
SENTRY MARTIN ELECTRONICS	403.550	SENTRY binary, SENTRY trinary		Multi
	433.920	SENTRY binary		433 et Multi
SERAI	310.000	OG/32		Multi
		OG/52, OG/54, OG/82, OG/84		433 et Multi
	433.920	OG/28, OG/48, OG/62, OG/64		433 et Multi
		OG/02, OG/04		433 et Multi
SICE	433.920	TX4 CLACK Bigfoot		433 et Multi
SILVELOX - INTRA	306.000	Green case with black buttons		Multi
	433.920	Silvelox Intra HSM4		433 et Multi
SIMBA	433.920	Simba RC1		433 et Multi
SIMINOR	433.920	ER2C4ACM, ER4C4ACM, ER2C4ACS, ER4C4ACS		433 et Multi
SKYLINK	300.000 310.000	MultiLink SD300M, Skylink 100, LD310M, SD310M		Multi
	318.000	Skylink Mtilink PD-318M		Multi
	390.000	Multilink CB-390M, CD-390M (versions compatible with Chamberlain)		Multi
SMD	433.920	LW433-1, LW433-2, LW433-4 : AM models only		433 et Multi
SOMFY	433.920	LEB TMW		433 et Multi
SPARKRITE	?	SRA2-2		Multi

STAGNOLI	433.920	ZEUS AZTR		433 et Multi
	868.350	ZEUS AZTR		Multi
STANLEY	310.000	24286		Multi
		1082		Multi
		1050		Multi
		1094		Multi
		1097		Multi
STARTEC	433.920	TXQ2		433 et Multi
STINGER	300.000 310.000 318.000 390.000	300MCD21V, 300MCD22V 310MCD21V, 310LID21V, 310LID22V 318ALD31V 390LMD21V, 390LMPB1V	 diff. colors	Multi
TAU	315.000	250 TXA2, 250 TXA4		Multi
	433.920	250 SLIM, 250K-SLIM, 250K-SLIMC		433 et Multi
		250TXD2, 250TXD4		433 et Multi
		250BUG2, 250BUG4		433 et Multi
		250T-4, 250T-4C		433 et Multi
TEC KEY	300.000	MK1010		Multi
TECNOMATIC	433.920	TQ433		433 et Multi
TEDSEN BERNER GFA Elektromaten	433.920	SKX1MD, SKX2MD, SKX3MD, SKX4MD		433 et Multi
		SKX1KD, SKX2KD, SKX4KD, SKX6KD		433 et Multi
		SKX1DL, SKX2DL, SKX3DL, SKX4DL		433 et Multi

		SKX1LC, SKX2LC, SKX3LC, SKX4LC		433 et Multi
		SKX1SL, SKX2SL, SKX3SL, SKX4SL		433 et Multi
		SKJ		433 et Multi
		SKX1WD, SKX2WD, SKX4WD, SKX11WD, SKX22WD, SKX44WD		433 et Multi
TELCOMA	306.000	RCS TP2		Multi
		RCST2, RCST4		Multi
	433.920	Telcoma EDGE 2, Telcoma EDGE 4		433 et Multi
		TANGO 2 SW, TANGO4 SW		433 et Multi
		TANGO BLUE 2, TANGO 4 BLUE, TANGO BLEU 2, TANGO BLEU 4		433 et Multi
		TANGO 2 N, TANGO 4 N		433 et Multi
		TANGO 2 SLIM, TANGO 4 SLIM		433 et Multi
		Telcoma Noire2, Noire4 Note: Rolling-code jumper should be removed from the receiver!		433 et Multi
		TANGO WIN3		433 et Multi
		TANGO2, TANGO4		433 et Multi
TELEMATIC	300.000	TL1, TL2		Multi
TKC	433.920	TSAW433		433 et Multi
TONKARR	287.000	TK2		Multi
TORAG	433.920	S429 1, S429 2, S429 4		433 et Multi
TORMATIC DORMA	433.920	HS, Dorma HS43 1E, HS43 2E, HS43 3E, HS43 4E		433 et Multi

		MAHS, Siebau, Novoferm, Dorma		433 et Multi
		MHS, MHS43-1		433 et Multi
TREMA	433.920	TO93TV1, TO93TV2, TO93TV4		433 et Multi
TUBAUTO	433.920	DIGITAL 101 433		433 et Multi
V2	306.000	TRR1_306		Multi
	318.000	TPS1K		Multi
	433.920	PHOENIX series: Phoenix2, Phoenix2P, Phoenix4, Phoenix4P, TXC2 Contr.47, TXC4 Contr.47, Handy2 Contr.47, Handy4 Contr.47, TRC4 Contr.47, TSC4 Contr.47 . Note:the receiver should be programmed with the rolling code feature disabled. When the code is learned, LED will blink for 6 times to highlight that the code is rolling.		433 et Multi
		TCP3		433 et Multi
		TCP3, ARC3		433 et Multi
		TCP3		433 et Multi
		TPR		433 et Multi
		T1SAW/433, T2SAW/433, T4SAW/433		433 et Multi
		TRR1, TRR2, TRR4		433 et Multi
		PMR2, PMR4		433 et Multi
	868.300	PHOENIX series: Phoenix2-868, Phoenix2P-868, Phoenix4-868, Phoenix4P-868. Note:the receiver should be		Multi

		programmed with the rolling code feature disabled. When the code is learned, LED will blink for 6 times to highlight that the code is rolling.		
VISONIC	315.000	WT100, WT100A, WT101, WT101A, WT102, WT104, WT-201, WT-201A, WT-201WP, WT-201AWP		Multi
	418.000	WT-100, WT-100A, WT-101, WT-101A, WT-102, WT-104, WT-201, WT-201A, WT-201WP, WT-201AWP		Multi
	433.920	WT 100, WT 100A, WT 101, WT 101A, WT 102, WT 104, WT 201, WT 201A, WT 201WP, WT 201AWP		433 et Multi
VSEG	433.920	CR SLIM		433 et Multi
VISA ELECTRONICS	306.000	VISA VRK 4021A		Multi
	433.920	Visa Beet 1, Visa Skippy		Multi
WAINE-DALTON	433.920	S429-1, S429-2, S429-4, S429-mini		433 et Multi
		S425		433 et Multi
WECLA CDS	433.920	433, 433_2		433 et Multi
ZULLAN	315.000	250TXA1H, 250TXA2H, 250TXA4H		Multi
OEM	315.000			Multi