












Compatible remote controls

<i>Company</i>	<i>Frequency</i>	<i>Models</i>	<i>Photo</i>	<i>Supported by:</i>
ADYX	433.920	ALIZE EM2C, ALIZE EM4C	 Cr_Multi	Multi 
AETERNA	433.920	TX433 1,2,4 buttons	 Cr_Multi	Multi 
ALLMATIC	306.000	ASMX2, ASMX4	 Cr_Multi	Multi
	433.920	AEMX1, AEMX2, AEMX4	 Cr_Multi	Multi, 
		EUROPE AUTO ARMY1, ARMY2, ARMY4	 Cr_Multi	Multi 
		MX1, MX2, MX4	 Cr_Multi	Multi 
ALLISTER	318.000	9931-318, 9931T-318	 Cr_Multi	Multi
ALLSTAR	288.000	111025 Allister Pulsar Quickcode	 Cr_Multi	Multi
		9921T-288, 9921MT, 9921TK, 9922T-288, 9923T-288, 9931-288, 9931T-288, 9931MT, 9931TK, 9931TK6, 8831T-288, 8832T-288, 8833T-288, 8821T-288, 8822T-288, 8823T-288, 8832TK	 Cr_Multi	Multi
		8833OCS-288	 Cr_Multi	Multi
	318.000	9921T-318, 9921MT, 9921TK, 9922T-318, 9923T-318, 9931-318, 9931T-318, 9931MT, 9931TK, 9931TK6, 8831T-318, 8832T-318, 8833T-318, 8821T-318, 8822T-318, 8823T-318, 8832TK	 Cr_Multi	Multi
		110995 Allister Pulsar Quickcode	 Cr_Multi	Multi
		8830OCS-318	 Cr_Multi	Multi
ALLTRONIK	433.920	S429_1, S429_2, S429_4, S429_M Be sure that your remote operates at 433.92MHz!	 Cr_Multi	Multi Rev.3, 
		S425	 Cr_Multi	Multi Rev.3, 
ANSONIC	433.920	SA 434-1E, SA434-2E, SA434-3E, SA434-4E	 Cr_Multi	Multi, 


		SA 434-1MINI, SA434-2MINI, SA 434-2Midi	 Cr_Multi	Multi, 
	868.350	SA 868-1E, SA 868-2E, SA868-3E, SA868-4E	 Cr_Multi	Multi
		SA 868-1mini/M, SA 868-2mini/M (dip switch version)	 Cr_Multi	Multi
APERTO	433.920	CPS1, CPS2, CPS4	 Cr_Multi	Multi, 
APRIMATIC	305.000	TS1, TS2	 Cr_Multi	Multi
AUTELCO	286-306	TX300T	 Cr_Multi	Multi
AVIDSEN	433.920	100601 micromark MM23164	 Cr_Multi	Multi, 
		104505	 Cr_Multi	Multi, 
		100951, 100955, 100550, 100400	 Cr_Multi	Multi, 
B&D BnD BD	433.920	062170/4333EBD, 062171, 4333A	 Cr_Multi	Multi, 
		062162	 Cr_Multi	Multi, 
		PTX4 059120 / 059116	 Cr_Multi	Multi, 
BANDY	433.920		 Cr_Multi	Multi, 
BELFOX	433.920	DHS433-1, DHS433-2, DHS433-4, dip switch version	 Cr_Multi	Multi, 
		DHS 433,92 (7733), dip switch version	 Cr_Multi	Multi, 
	868.350	DHS 868,3, dipswitch version	 Cr_Multi	Multi
		HS 868-20	 Cr_Multi	Multi
BENINCA'	306.000	LOT1A, LOT2A, LOT4A	 Cr_Multi	Multi
		LOTX1A, LOTX2A, LOTX4A	 Cr_Multi	Multi
		LO.TX2PS	 Cr_Multi	Multi
	433.920	LOT1W, LOT2W, LOT4W	 Cr_Multi	Multi, 


		LOT2WMS	 Cr_Multi	Multi 
		T2WK, T4WK	 Cr_Multi	Multi 
		LOTX1W, LOTX2W, LOTX4W	 Cr_Multi	Multi, 
		TO.GO2WP, TO.GO4WP, TO.GO2WK, TO.GO4WK	 Cr_Multi	Multi, 
BERNER	868.300	Berner BHS140	 Cr_Multi	Multi Rev.04e
		Berner BHS130	 Cr_Multi	Multi Rev.04f
BESIDE	433.920	BEZAP	 Cr_Multi	Multi, 
		HIT	 Cr_Multi	Multi, 
BETA ELETTRONICA	315.000	BETALARM 6500	 Cr_Multi	Multi
	330.000	BETALARM 5500	 Cr_Multi	Multi
BFT	306.000	RCS	 Cr_Multi	Multi R3
	315.000	VTM1, VTM2, VTM4	 Cr_Multi	Multi
	418.000	GT01, GT02, GT04	 Cr_Multi	Multi
	433.920	TE01, TE02 (TEO1, TEO2)	 Cr_Multi	Multi 
		TE04 (TEO4)	 Cr_Multi	Multi, 
		MITTO 2, MITTO 4: Only if the receiver is CLONIX 1 or CLONIX 2 with DIP2 in ON position	 Cr_Multi	Multi 
BREDA	433.920	Breda TOP432SA Cr_Multi	Like CAME TOP432SA, blue	Multi 
CAME	315.000	Came T312M, T314M	Cr_Multi	Multi
		Came TOP312, TOP314	 Cr_Multi	Multi
		Came TOP432NA, TOP434NA	 Cr_Multi	Multi
	433.920	Came T432, T434, TOP432A, TOP434A, TOP432, TOP432NA,	 Cr_Multi	Multi 


		TOP434NA, TAM432, TAM434, TAM438		
		Came TOP432M, TOP434M	 Cr_Multi	Multi, 
		Came TAM432SA	 Cr_Multi	Multi, 
		Came TOP432SA	 Cr_Multi	Multi, 
		Came TOP432NA, TOP434NA	 Cr_Multi	Multi, 
		Came TWIN2, TWIN4	 Cr_Multi	Multi, 
		CAME TOP-432EV, TOP-434EV	 Cr_Multi	Multi, 
CARDIN	868.350	CAME TOP862NA, Came TOP864NA	 Cr_Multi	Multi
	300.000	S300	 Cr_Multi	Multi
	310.000	S301, S302	 Cr_Multi	Multi
CARPER	433.920	S476 TX2, S476TX4	 Cr_Multi	Multi, 
	300.000	C300, C310, C318, C318T	 Cr_Multi	Multi
	310.000			
CASALI GENIUS	330.000			
	433.920	Genius 433 2, Genius 433 3, JA400 TM433, JA401 TM433	 Cr_Multi	Multi, 
CASIT	306.000	ERTS92B, ERTS92T	 Cr_Multi	Multi
	433.920	ERTS92B, ERTS92T	 Cr_Multi	Multi, 
		ERTS20DB, ERTS20DQ	 Cr_Multi	Multi, 
		ERTS476D, ERTS476Q	 Cr_Multi	Multi, 
		TXS1, TXS2, TXS3, TXS4, TXS6 ERTS97B, ERTS97T	 Cr_Multi	Multi, 
CEDAMATIC	305.000	Cedamatic CTX1S, CTX2S, CTX4S	 Cr_Multi	Multi
	433.920	Cedamatic AEMX1, AEMX2, AEMX4	 Cr_Multi	Multi, 
CELINSA	433.920	S10 1, S10 2, SAW1, SAW2	 Cr_Multi	Multi, 

CENTURION	433.920	CLASSIC, SMART, SMART2	 Cr_Multi	Multi, 
CHAMBERLAIN LIFTMASTER MOTORLIFT SEARS CRAFTSMAN	300.000	Chamberlain 300MC (multicode)	 Cr_Multi	Multi
	315.000	333LM	 Cr_Multi	Multi
		360LM, 362LM, 363LM	 Cr_Multi	Multi
	390.000	50CB, 53CB, 750CB, 753CB, 50LM, 53LM, 61LM, 62LM, 63LM, 139.53100, 139.53110, 139.53200, 139.53210	 Cr_Multi	Multi
		54CB, 756CB, 54LM, 64LM, 859CB	 Cr_Multi	Multi
		850CB, 853CB, 959CB, 81LM, 82LM, 83LM, 84LM, 99LM	 Cr_Multi	Multi
		33LM	 Cr_Multi	Multi
	418.000	4180, 4182, 4183	 Cr_Multi	Multi
		4185	 Cr_Multi	Multi
		787 remote keyless entry	 Cr_Multi	Multi
	433.920	4330E, 4332E, 4333E	 Cr_Multi	Multi, 
		4335E	 Cr_Multi	Multi, 
COSTEL	300.000	Minitix	Cr_Multi	Multi
CPS	433.920	TCP3, CPS, Jolly 4	 Cr_Multi	Multi, 
		CPS1 TCP3, CPS2 TCP3, CPS4 TCP3 EM1CV, EM2CV, EM4CV	 Cr_Multi	Multi, 
DASPI	433.920	Daspi Happy2 433, Daspi Pops2	 Cr_Multi	Multi, 
		Daspi Zero2, Zero2CLO, Zero4CLO	 Cr_Multi	Multi, 
DEA	306.000	306 1, 306 2, 306 4	 Cr_Multi	Multi
		306	 Cr_Multi	Multi




	433.920	433 1, 433 2, 433 4, Gold S1, Gold S2 Dea Gold 238 S1, Dea Gold 238 S2, Dea Gold 239 S4	 Cr_Multi	Multi, 
		Genie	 Cr_Multi	Multi, 
		Punto S2	 Cr_Multi	Multi, 
		Dea MIO TD2, MIO TD4	 Cr_Multi	Multi, 
DELMA	300.000	Apollo 300, ELSAMEC Apollo 300	 Cr_Multi	Multi
		Mizard 300 1, Mizard 300 2, King	 Cr_Multi	Multi
	433.920	Mizard 433 1, Mizard 433 2	 Cr_Multi	Multi, 
		King 433 2	 Cr_Multi	Multi, 
		Style Copy 2CH (this is a code duplicator)	 Cr_Multi	Multi, 
DICKERT	433.920	Dickert MAHS433 01, MAHS433 04 Note: we can NOT guarantee that it can be duplicated, because it depends by the receiver.	 Cr_Multi	Multi, 
		Dickert S10-433A1L00, S10-433A4L00, S20-433A1L00, S20-433A4L00, S20-433A1000, S20-433A4000 Note: only RED buttons model can be duplicated!	 Cr_Multi	Multi, 
		Dickert S5-433-A2L00, S5U-433-A2L00 Note: only RED buttons model can be duplicated!	 Cr_Multi	Multi, 
	868.350	Dickert HS868-21 Note: only RED buttons model can be duplicated!	 Cr_Multi	Multi
		Dickert S5-868A2L00, S5U-868A2L00 Note: only RED buttons model can be duplicated!	 Cr_Multi	Multi
		Dickert S10-868A100, S10-868A400, S20-868A1L00, S20-868A4L00, S20-868A1000, S20-	 Cr_Multi	Multi

		868A4000 Note: only RED buttons model can be duplicated!		
		Dickert S5-868A2L01, S10-868A1L01, S10-868-A4L06, green buttons	 Cr_Multi	Multi
DIGICODE	300.000 310.000	DC5010, DC5012, DC5030, DC5032, DC5040, DC5042, DC5060, DC5062, DC5070, DC5072	 Cr_Multi	Multi
DITEC	433.920	GOL4C	 Cr_Multi	Multi, 
		GOL4 Note: These transmitters are rolling code and cannot be duplicated, but if you have a GOL4C device, you can duplicate it on Four or Multi, and it works with all the DITEC receivers.	 Cr_Multi	Multi, 
		BIX LS2, BIX LP2, BIX LG4 Note: These transmitters are rolling code and cannot be duplicated, but if you have a GOL4C device, you can duplicate it on Four or Multi, and it works with all the DITEC receivers.	 Cr_Multi	Multi, 
DOITRAND FDOITRAND	433.920	MPSTF2E JAUNE, MPSTF4E, HYPERPHONE MPSTF2E_GRISE	 Cr_Multi	Multi, 
		TS2DE, TS4DE	 Cr_Multi	Multi, 
DOORHAN	433.920		 Cr_Multi	Multi, 
DOORMATIC	433.920	SAW	 Cr_Multi	Multi, 
DUCATI ALLDUCKS	433.920	TSAW1, TSAW2, TSAW3, TSAW4, 124 ELBER TSAW1, TSAW2, TSAW3, TSAW4 RONDY TSAW1, RONDY TSAW2, RONDY TSAW3	 Cr_Multi	Multi, 
		TPR10-A, TPR20-A RONDY TPR10_A, RONDY TPR20_A	 Cr_Multi	Multi, 
		TE2	 Cr_Multi	Multi, 



		HC6203, 6203: only blue with transparent buttons, and transparent with transparent buttons	 Cr_Multi	Multi, 
ECP	292.000	FIX 292 MHz F105611	 Cr_Multi	Multi
		KEY 292 MHz F106038	 Cr_Multi	Multi
ELBE	433.920	501, 502, 504	 Cr_Multi	Multi, 
		502a, 504a	 Cr_Multi	Multi, 
		502, 504	 Cr_Multi	Multi, 
ELCA	300.000	Aster 1100, Aster 1101	 Cr_Multi	Multi
	433.920	IRIS, IRIS 9CH. Model 433D only! Both colors red and blue	 Cr_Multi	Multi, 
		ASTER2	 Cr_Multi	Multi, 
		Aster 1000, Aster1001. Model 433D only! Colors: black, blue, light grey	 Cr_Multi	Multi, 
		GEMINI 9CH	 Cr_Multi	Multi, 
		VIRGO	 Cr_Multi	Multi, 
ELDAT MFZ	433.920	Eldat Basewave RT20-4103M-01, RT20-4104M-01, RT35-4104M-01, RT21-4101M-01, RT21-4102M-01, MFZ 400033	 Cr_Multi	Multi, 
		Eldat Basewave RT28-4101M-01, RT27-4101M-01, RT26-4101M-02, RT21-4125M-01, RT21-4139M-01, RT21-4139M-02, RT31-4139M-01, RT31-4139M-02, RTC02-4104M-01	 Cr_Multi	Multi, 
	868.300	Eldat Basewave RT20-5004M-01, RT20-5003M-01, RT35-5004M-01, RT21-5001M-01, RT21-5002M-01	 Cr_Multi	Multi
		Eldat Basewave RT28-5001M-01, RT27-5001M-01, RT26-5001M-02, RT21-5025M-01, RT21-5039M-01, RT21-5039M-02, RT31-5039M-01, RT31-5039M-02, RTC02-5004M-01	 Cr_Multi	Multi




ELEK	300.000	KTM194B	 Cr_Multi	Multi
		KTR4	 Cr_Multi	Multi
ELV CONRAD	868.350	FS20 S4, FS20 S8, FS20 S8-2, FS20 S16, FS20S16R, FS20 S20-2, FS20 S20-3	 Cr_Multi	Multi Rev.4
ELVOX	433.920	Elvox ET	 Cr_Multi	Multi, 
		Elvox ET03, ET04	 Cr_Multi	Multi, 
	868.350	Elvox ET08	 Cr_Multi	Multi
EMFA	287.000	ET1, ET2, ET3	 Cr_Multi	Multi
	308.000	ES_1, ES_2	 Cr_Multi	Multi
ERONE	433.920	SETDS39433E2, SETDS39433E4	 Cr_Multi	Multi, 
ERREKA	289.000	Erreka E20, Erreka E22	 Cr_Multi	Multi
	433.920	Erreka Luna, Erreka SMAT 1 RESON 1, RESON 2, RESON 3	 Cr_Multi	Multi, 
EUROPE AUTOMATISMES	306.000	ASMY1, ASMY2, ASMY4	 Cr_Multi	Multi
	433.920	ARMY1, ARMY2, ARMY4	 Cr_Multi	Multi, 
		S1, S2, S3	 Cr_Multi	Multi, 
FAAC	300.000	TM300S, TM300S05 H Faac TM1 300, TM2 300, TM3 300	 Cr_Multi	Multi
	315.000	T1, T2, T3 Faac TM1 315, TM2 315, TM3 315	 Cr_Multi	Multi
	330.000	TM1, TM2, TM3 Faac TM1 330, TM2 330, TM3 330	 Cr_Multi	Multi
	418.000	TM1 418 DS, TM2 418 DS, TM3 418 DS	 Cr_Multi	Multi
		TM 418SL, TM1 418SL, TM2 418 SL, TM3 418SL	 Cr_Multi	Multi


	433.920	TM1 433 DS, TM2 433 DS, TM3 433 DS TM1 433DS DPH, TM2 433DS DPH, TM3 433DS DPH	 Cr_Multi	Multi, 
		TML2 433 SLR, TML4 433 SLR, TML2-433-SLR, TML4-433-SLR, TML2 433 ESL, TML4 433 ESL	 Cr_Multi	Multi, 
		TML2 433 SLP, TML4 433 SLP, TML2-433-SLP, TML4-433-SLP	 Cr_Multi	Multi, 
	868.350	TM1 868 DS, TM2 868 DS, TM3 868 DS TM1 868DS DPH, TM2 868DS DPH, TM3 868DS DPH	 Cr_Multi	Multi
FADINI BPT	315.000	ASTRO75-1, ASTRO75-2, ASTRO75-4	 Cr_Multi	Multi
	433.920	433 2M, Astro43_2m	 Cr_Multi	Multi, 
		Astro433-2, Astro433-4, Astro43-2, Astro43-4	 Cr_Multi	Multi, 
FERPORT	433.920	Tac1, Tac2, Tac4, Tac1k, Tac2k, Tac4k, Tac2kr	 Cr_Multi	Multi, 
FORSA	287.000	Forsa Trieme	 Cr_Multi	Multi
FUNKMODUL ELSECO	433.920	T433A2K1, T433A2K2	 Cr_Multi	Multi, 
		T433A2K4, T433A2K4n	 Cr_Multi	Multi, 
GIBIDI	306.000	TS2M	 Cr_Multi	Multi
	433.920	Open TMB 433, OPEN TMQ 433, OPEN OUT 2, OPEN OUT 4	 Cr_Multi	Multi, 
GOBBATO	306.000	T306	 Cr_Multi	Multi
GRIFFON	403.55	Griffon 404 MHz dip switch remotes and duplicating remotes	 Cr_Multi	Multi
	433.92	Griffon 433 MHz dip switch remotes and duplicating remotes	 Cr_Multi	Multi, 
GTO	318.000	GTO Mighty Mule 1/2 buttons, RB741, RB742	 Cr_Multi	Multi
		GTO Mighty Mule 3 buttons, RB743	 Cr_Multi	Multi



GULLIVER	306.000	MDRQ 306		Cr_Multi	Multi
	433.920	MDW 2E		Cr_Multi	Multi, 
HAUSS	433.920	Pocket 3750-1, Pocket3750-2, Pocket 3750-4		Cr_Multi	Multi, 
HEDDOF	318.000	P219-1, P219-2		Cr_Multi	Multi
		P220-1, P220-2, P220-3		Cr_Multi	Multi
HORMANN HOERMANN	433.920	HSM2, HSM4, yellow buttons Please note that, in Netherlands, Hoermann sell this kind of remote control which transmit a rolling code: in this case it cannot be duplicated!		Cr_Multi	Multi, 
	868.300	HS1, HS2, HS4, blue buttons		Cr_Multi	Multi
		HSD2		Cr_Multi	Multi
		HSE2, HSE4, blue buttons		Cr_Multi	Multi
		HSM2, HSM4, blue buttons		Cr_Multi	Multi
		HSP4, blue buttons		Cr_Multi	Multi
		HSS2, HSS4, blue buttons		Cr_Multi	Multi
		HSZ1-868, HSZ2-868		Cr_Multi	Multi
HRC	433.920			Cr_Multi	Multi, 
JAY	433.920	UBEI x1 SL1		Cr_Multi	Multi, 
		UBET 11, UBET 21, UBET 31, UBET 41, UBET 61Ã,		Cr_Multi	Multi, 
JCM	290.000	EC1, EC2, EC3, ET1, ET2, ET3		Cr_Multi	Multi


KEY AUTOMATION	433.920	900TXB-42, 900TXB-42N, 900TXP-42, 900TXP-42N	 Cr_Multi	Multi, 
		900TXB-44, 900TXG-44	 Cr_Multi	Multi, 
		900SUB-44, 900SUB-44N, 900SUB-44W, 900SUB-44WN	 Cr_Multi	Multi, 
		900TXK-42, 900TXW-42, 900TXK-44, 900TXW-44	 Cr_Multi	Multi, 
KING	433.920	Note: receiver should be setup with rolling code feature disabled	Cr_Multi	Multi, 
LABEL IUPPITER	306.000	MDR, IUPPITER 306	 Cr_Multi	Multi
	433.920	RJW/1E, RJW/2E, RJW/4E, RJW/12E	 Cr_Multi	Multi, 
		MDW/1E, MDW/2E	 Cr_Multi	Multi, 
LEB	306.000	TSA4	 Cr_Multi	Multi
	433.920	TMW	 Cr_Multi	Multi, 
		TSAW2N, TSAW4N	 Cr_Multi	Multi, 
		TCP3Ã, (this is a code duplicator)	 Cr_Multi	Multi, 
		TRK4 Note: receiver should be configured to disable rolling check.	 Cr_Multi	Multi, 
		TPW4	 Cr_Multi	Multi, 
	868.300	TPK4	 Cr_Multi	Multi
LINCE	302.000	LE TX1, LE TX2	Cr_Multi	Multi
	433.920	LR 2035	Cr_Multi	Multi, 
LINEAR	300.000 310.000	MULTI-CODE 308911, 308913, 1089	 Cr_Multi	Multi
		MULTI-CODE 412001, 414001, 109410, 109710	 Cr_Multi	Multi
		MULTICODE 306010, 307010, 108210	 Cr_Multi	Multi


		MULTI-CODE 308301, 308302		Cr_Multi	Multi
		MULTI-CODE 105015		Cr_Multi	Multi
	310.000	Delta3 Moore-o-Matic: DT, DT2, DT2A, DT22A, DTC, DTD		Cr_Multi	Multi
		Delta 3 Moore-o-Matic: DT3, DT4		Cr_Multi	Multi
		Delta 3 Moore-o-Matic: Mini-T LB "LadyBug"		Cr_Multi	Multi
	312.000	Delta3 DTK (canada)		Cr_Multi	Multi
MA SYSTEM	433.920	MA TX1, MA TX2, MA TX3		Cr_Multi	Multi, 
MARANTEC	418.000	D212, D222, D232		Cr_Multi	Multi
	433.920	D101		Cr_Multi	Multi, 
		D12		Cr_Multi	Multi, 
		D212, D222, D232		Cr_Multi	Multi, 
		Digital 302, D302		Cr_Multi	Multi Rev.4, 
		Digital 304, D304		Cr_Multi	Multi Rev.4, 
	868.300	Digital 302, D302		Cr_Multi	Multi Rev.4 Rev.4
		Digital 304, D304		Cr_Multi	Multi Rev.4 Rev.4
MCZ	433.920	Aster		Cr_Multi	Multi, 
MEIÄfÅ,NER MEISSNER	433.920	LW433-1, LW433-2, LW433-4		Cr_Multi	Multi, 
		Pocket 3750 1, 2, 4		Cr_Multi	Multi, 
MKTECHNO MK-TECHNO	306.000	MK-TECHNO TX1 and MKTECHNO TX2 with RED LED		Cr_Multi	Multi
MONSEIGNEUR	433.920	ARC2, ARC4		Cr_Multi	Multi, 



		TDR 400 3845, TDR 400 3846, TDR 400 3847 T1SAW433, T2SAW433, T4SAW433	 Cr_Multi	Multi, 
MOTORLINE STATEUROP	433.920	MX1, MX2, MX3, MX4, MX6 MX11, MX12, MX13	 Cr_Multi	Multi, 
MOTOSTAR	433.920	CLIKSTAR2, CLICKSTAR4 CLICK-4M, CLICKSTAR RE 532, CLICKSTAR RE 534	 Cr_Multi	Multi, 
NICE	306.000	EASY S1, S2, S4	 Cr_Multi	Multi
	433.920	FLO1, FLO2, FLO4	 Cr_Multi	Multi, 
		VERY VE	 Cr_Multi	Multi, 
NOLOGO	306.000		 Cr_Multi	Multi
	433.920	ECO DIP	 Cr_Multi	Multi, 
NOVOTECNICA	306.000	BIT N1, BIT N2	 Cr_Multi	Multi
		BIT NT1, BIT NT2, BIT NT4	 Cr_Multi	Multi
OG	433.920	OG62, OG64	 Cr_Multi	Multi, 
O&O OeO, OandO,OetO	306.000	OeO TX2, TX4 (green buttons)	 Cr_Multi	Multi
	433.920	OeO TX4-E, TX2-E (red buttons)	 Cr_Multi	Multi, 
		OeO T-COM DS 4-2, O&O T-COM DS 4-4	 Cr_Multi	Multi, 
OPENOUT	306.000	TS2M	 Cr_Multi	Multi
	433.920	TMQ 433 2, TMQ 433 4	 Cr_Multi	Multi, 
PIAZZETTA	433.920	4 buttons for wood/pellet heater	 Cr_Multi	Multi, 
PORTAMATIC	433.920	MPH01, MPH02	 Cr_Multi	Multi, 



POWERFIX Profi (Lidl)	433.920	RCB-A 3600R	 Cr_Multi	Multi, 
PRASTEL	306.000	NCSMT1, NCSMT2P, NCSMT4P	 Cr_Multi	Multi
		KMFT2P, KMFT4P, KMFT2P93, KMFT4P93	 Cr_Multi	Multi
	433.920	MPSTF2E, MPSTF4E	 Cr_Multi	Multi, 
PROEM	433.920	ER2C4ACM, ER4C4ACM	 Cr_Multi	Multi, 
PROGET	433.920	ETY_433N2, ETY 433N4	 Cr_Multi	Multi, 
		EMI433-N2	 Cr_Multi	Multi, 
PROTECO	433.920	TX433	 Cr_Multi	Multi, 
		EUROMATIC	 Cr_Multi	Multi, 
		HIT	 Cr_Multi	Multi, 
PUJOL	288.000	JCM TRINARIO 1, TRINARIO 2, TRINARIO 3	 Cr_Multi	Multi
	288.000	TT1, TT2, TRINARIO 1, TRINARIO 2	 Cr_Multi	Multi
PULSAR	318.000	9931-318, 9931T-318	 Cr_Multi	Multi
QUASAR	287.000	Tx SA4, Serie Argento, SA	 Cr_Multi	Multi
	287.000	TXSA2T	 Cr_Multi	Multi
	306.000	300 2, 300 4	 Cr_Multi	Multi
	433.920	433 TANGO SLIM BLEU	 Cr_Multi	Multi, 
QUICK	433.92	Model: 302	 Cr_Multi	Multi
RADIODIGIT	291.000	TBM, TCM	 Cr_Multi	Multi
ROGER	433.920	R80/TX12, R80/TX14, R80/TX12R, R80/TX14R	 Cr_Multi	Multi, 

		H80/TX22	 Cr_Multi	
		G80/TX32, G80/TX34, G80/TX32R, G80/TX34R	 Cr_Multi	
SEA	433.920		 Cr_Multi	Multi, 
		SMART433_TX2_DIP, SMART433_TX3_DIP SMART433_TX2_COPY, SMART433_TX3_COPY Smart2 Dip Switch, Smart3 Dip Switch	 Cr_Multi	Multi, 
	868.350	231103, SEA868_4	 Cr_Multi	Multi
		231103, Head2 Dip Switch	 Cr_Multi	Multi
		SMART868-TX2-DIP, SMART868-TX3-DIP Smart2 Dip Switch, Smart3 Dip Switch	 Cr_Multi	Multi
SEAV	306/330	TX1, TX2, TX3, TX4, TX1/330 TX2/330, TX3/330, TX4/330	 Cr_Multi	Multi
	433.920	TXS1, TXS2, TXS3, TXS4	 Cr_Multi	Multi, 
		Behappy S1, Behappy S2, Behappy S3	 Cr_Multi	Multi, 
		Be Easy TX, Be Easy Murale2	 Cr_Multi	Multi, 
		BeSmart S2, BeSmart S4	 Cr_Multi	Multi, 
		BeFree S1	 Cr_Multi	Multi, 
	868.300	BeSmart H2, BeSmart H4	 Cr_Multi	Multi
		BeFree H1	 Cr_Multi	Multi
SECURVERA	433.920	SV R2C	 Cr_Multi	Multi, 
		SV R2C	 Cr_Multi	Multi, 
		SV R4C	 Cr_Multi	Multi, 
		SV R6C	 Cr_Multi	Multi, 

SENDER	433.920		 Cr_Multi	Multi, 
SENTRY MARTIN ELECTRONICS	403.550	SENTRY binary, SENTRY trinary	 Cr_Multi	Multi
	433.920	SENTRY binary	 Cr_Multi	Multi, 
SERAI	310.000	OG/32	 Cr_Multi	Multi
	433.920	OG/52, OG/54, OG/82, OG/84	 Cr_Multi	Multi, 
		OG/28, OG/48, OG/62, OG/64	 Cr_Multi	Multi, 
		OG/02, OG/04	 Cr_Multi	Multi, 
SICE	433.920	TX4 CLACK Bigfoot	 Cr_Multi	Multi, 
SILVELOX - INTRA	306.000	Green case with black buttons	 Cr_Multi	Multi
	433.920	Silvelox Intra HSM4	 Cr_Multi	Multi, 
SIMBA	433.920	Simba RC1	 Cr_Multi	Multi, 
SIMINOR	433.920	ER2C4ACM, ER4C4ACM, ER2C4ACS, ER4C4ACS	 Cr_Multi	Multi, 
SKYLINK	300.000 310.000	MultiLink SD300M, Skylink 100, LD310M, SD310M	 Cr_Multi	Multi
	318.000	Skylink Mtilink PD-318M	 Cr_Multi	Multi
	390.000	Multilink CB-390M, CD-390M (versions compatible with Chamberlain)	 Cr_Multi	Multi
SMD	433.920	LW433-1, LW433-2, LW433-4 : AM models only	 Cr_Multi	Multi, 
SOMFY	433.920	LEB TMW	 Cr_Multi	Multi, 
SPARKRITE	?	SRA2-2	 Cr_Multi	Multi

STAGNOLI	433.920	ZEUS AZTR	 Cr_Multi	Multi, 
	868.350	ZEUS AZTR	 Cr_Multi	Multi
STANLEY	310.000	24286	 Cr_Multi	Multi
		1082	 Cr_Multi	Multi
		1050	 Cr_Multi	Multi
		1094	 Cr_Multi	Multi
		1097	 Cr_Multi	Multi
STARTEC	433.920	TXQ2	 Cr_Multi	Multi, 
STINGER	300.000 310.000 318.000 390.000	300MCD21V, 300MCD22V 310MCD21V, 310LID21V, 310LID22V 318ALD31V 390LMD21V, 390LMPB1V	 Cr_Multi diff. colors	Multi
TAU	315.000	250 TXA2, 250 TXA4	 Cr_Multi	Multi
	433.920	250 SLIM, 250K-SLIM, 250K-SLIMC	 Cr_Multi	Multi, 
		250TXD2, 250TXD4	 Cr_Multi	Multi, 
		250BUG2, 250BUG4	 Cr_Multi	Multi, 
		250T-4, 250T-4C	 Cr_Multi	Multi, 
TEC KEY	300.000	MK1010	 Cr_Multi	Multi
TECNOMATIC	433.920	TQ433	 Cr_Multi	Multi, 
TEDSEN BERNER GFA Elektromaten	433.920	SKX1MD, SKX2MD, SKX3MD, SKX4MD	 Cr_Multi	Multi, 
		SKX1KD, SKX2KD, SKX4KD, SKX6KD	 Cr_Multi	Multi, 
		SKX1DL, SKX2DL, SKX3DL, SKX4DL	 Cr_Multi	Multi, 

		SKX1LC, SKX2LC, SKX3LC, SKX4LC	 Cr_Multi	Multi, 
		SKX1SL, SKX2SL, SKX3SL, SKX4SL	 Cr_Multi	Multi, 
		SKJ	 Cr_Multi	Multi, 
		SKX1WD, SKX2WD, SKX4WD, SKX11WD, SKX22WD, SKX44WD	 Cr_Multi	Multi, 
TELCOMA	306.000	RCS TP2	 Cr_Multi	Multi Rev.4
		RCST2, RCST4	 Cr_Multi	Multi Rev.4
	433.920	Telcoma EDGE 2, Telcoma EDGE 4	 Cr_Multi	Multi, 
		TANGO 2 SW, TANGO4 SW	 Cr_Multi	Multi, 
		TANGO BLUE 2, TANGO 4 BLUE, TANGO BLEU 2, TANGO BLEU 4	 Cr_Multi	Multi, 
		TANGO 2 N, TANGO 4 N	 Cr_Multi	Multi, 
		TANGO 2 SLIM, TANGO 4 SLIM	 Cr_Multi	Multi, 
		Telcoma Noire2, Noire4 Note: Rolling-code jumper should be removed from the receiver!	 Cr_Multi	Multi, 
		TANGO WIN3	 Cr_Multi	Multi, 
		TANGO2, TANGO4	 Cr_Multi	Multi, 
TELEMATIC	300.000	TL1, TL2	 Cr_Multi	Multi
TKC	433.920	TSAW433	 Cr_Multi	Multi, 
TONKARR	287.000	TK2	 Cr_Multi	Multi
TORAG	433.920	S429 1, S429 2, S429 4	 Cr_Multi	Multi, 
TORMATIC DORMA	433.920	HS, Dorma HS43 1E, HS43 2E, HS43 3E, HS43 4E	 Cr_Multi	Multi, 

		MAHS, Siebau, Novoferm, Dorma	 Cr_Multi	Multi, 
		MHS, MHS43-1	 Cr_Multi	Multi, 
TREMA	433.920	TO93TV1, TO93TV2, TO93TV4	 Cr_Multi	Multi, 
TUBAUTO	433.920	DIGITAL 101 433	 Cr_Multi	Multi, 
V2	306.000	TRR1_306	 Cr_Multi	Multi
	318.000	TPS1K	 Cr_Multi	Multi
	433.920	PHOENIX series: Phoenix2, Phoenix2P, Phoenix4, Phoenix4P, TXC2 Contr.47, TXC4 Contr.47, Handy2 Contr.47, Handy4 Contr.47, TRC4 Contr.47, TSC4 Contr.47 . Note:the receiver should be programmed with the rolling code feature disabled. When the code is learned, LED will blink for 6 times to highlight that the code is rolling.	 Cr_Multi	Multi, 
		TCP3	 Cr_Multi	Multi, 
		TCP3, ARC3	 Cr_Multi	Multi, 
		TCP3	 Cr_Multi	Multi, 
		TPR	 Cr_Multi	Multi, 
		T1SAW/433, T2SAW/433, T4SAW/433	 Cr_Multi	Multi, 
		TRR1, TRR2, TRR4	 Cr_Multi	Multi, 
		PMR2, PMR4	 Cr_Multi	Multi, 
	868.300	PHOENIX series: Phoenix2-868, Phoenix2P-868, Phoenix4-868, Phoenix4P-868. Note:the receiver should be	 Cr_Multi	Multi

		programmed with the rolling code feature disabled. When the code is learned, LED will blink for 6 times to highlight that the code is rolling.		
VISONIC	315.000	WT100, WT100A, WT101, WT101A, WT102, WT104, WT-201, WT-201A, WT-201WP, WT-201AWP	 Cr_Multi	Multi
	418.000	WT-100, WT-100A, WT-101, WT-101A, WT-102, WT-104, WT-201, WT-201A, WT-201WP, WT-201AWP		Multi
	433.920	WT 100, WT 100A, WT 101, WT 101A, WT 102, WT 104, WT 201, WT 201A, WT 201WP, WT 201AWP		Multi, 
VSEG	433.920	CR SLIM	 Cr_Multi	Multi, 
VISA ELECTRONICS	306.000	VISA VRK 4021A	Cr_Multi	Multi
	433.920	Visa Beet 1, Visa Skippy	Cr_Multi	Multi
WAINE-DALTON	433.920	S429-1, S429-2, S429-4, S429-mini	 Cr_Multi	Multi, 
		S425	 Cr_Multi	Multi, 
WECLA CDS	433.920	433, 433_2	 Cr_Multi	Multi, 
ZULLAN	315.000	250TXA1H, 250TXA2H, 250TXA4H	 Cr_Multi	Multi
OEM	315.000		 Cr_Multi	Multi