

NOLOGO

- Radiocomando compatibile, codici rolling-code.
- Memorizza quattro differenti radiocomandi uno per pulsante.

CARTY-R



PROCEDURA INIZIALE

1 - Posizionare il radiocomando da copiare X di fronte al **CARTY-R** a circa 4 cm.

2 - Premere e tener premuto il pulsante **1** il LED è **verde**

3 - Premere **quattro** volte il pulsante **2** il LED diventa **rosso**

4 - Rilasciare i pulsanti

Il LED emette un lampeggio **rosso** breve circa ogni 2,5" (8 lampeggi) per un tempo massimo di 20" **entro i quali.....**

DUPLICARE RADIOCOMANDI ROLLING SENZA IL CODICE SORGENTE

Tutti i radiocomandi rolling elencati nella lista scaricabile dal sito, ad esclusione di quelli con il codice sorgente descritti nei paragrafi successivi.

- 5 - Premere e tener premuto il pulsante da copiare del radiocomando originale e attendere alcuni secondi fino a quando il LED del **CARTY-R** lampeggi più velocemente a conferma del corretto apprendimento del codice.
- 6 - Mentre il LED lampeggia (*max 20"*), premere e mantener premuto il pulsante del **CARTY-R** sul quale si desidera inserire il codice appena appreso fino allo spegnimento del LED a conferma del corretto apprendimento del codice.

NELLA RADIO-RICEVENTE

Scegliere il "**MODE**" giusto nella tabella: **MODE FAST** oppure **MODE ENTER** oppure **MODE MANUAL**

DUPLICARE RADIOCOMANDI ROLLING FAAC / GENIUS CON IL CODICE SORGENTE

FAAC 433 / 868 **GENIUS** 433 / 868

Il radiocomando da copiare deve essere un MASTER, lo sarà se premendo un pulsante il LED emetterà subito un doppio lampeggio anziché subito una luce fissa.

- 5 - Premere e mantenere premuto il pulsante da copiare del radiocomando originale, fino a che il LED del **CARTY-R** si accenderà fisso.
- 6 - Rilasciare il pulsante ed attendere.
- 7 - Il LED del **CARTY-R** poco dopo emetterà un lampeggio breve circa ogni 2".
Questo avverte l'operatore che è necessario emettere il codice sorgente.
- 8 - Premere contemporaneamente i pulsanti 1 e 2 del radiocomando **FAAC/GENIUS** e rilasciarli
- 9 - Il LED del radiocomando **FAAC/GENIUS** lampeggia (*max 9"*)
- 10 - Premere e tener premuto il pulsante da copiare del radiocomando **FAAC/GENIUS** e attendere alcuni secondi fino a quando il LED del **CARTY-R** lampeggi più velocemente.
- 11 - Premere il pulsante in cui si vuole memorizzare il codice e mantenerlo premuto fino a quando il LED del **CARTY-R** si spegne.

NELLA RADIO-RICEVENTE

Verificare il corretto funzionamento del nuovo radiocomando **CARTY-R**

Vedi **FAAC / GENIUS: MODE FAST** oppure **MODE ENTER** premendo il pulsante 2 volte.

NOLOGO

IT RADIOCOMANDO CARTY-R

DUPLICARE RADIOCOMANDI ROLLING BFT CON IL CODICE SORGENTE

BFT

- 5 - Premere e mantenere premuto il pulsante da copiare del radiocomando originale, fino a che il LED del **CARTY-R** si accenderà fisso.
- 6 - Rilasciare il pulsante ed attendere.
- 7 - Il LED del **CARTY-R** poco dopo emetterà un lampeggio breve circa ogni 2".
Questo avverte l'operatore che è necessario emettere il codice sorgente.
- 8 - Premere contemporaneamente i pulsanti 1 e 2 (oppure il pulsante nascosto sul retro con uno spillo) del radiocomando **BFT** e rilasciarli fino all'accensione del LED **BFT**.
- 9 - Il LED del **CARTY-R** ora lampeggia più veloce.
- 10 - Premere e mantener premuto il pulsante del **CARTY-R** sul quale si desidera inserire il codice appena appreso ed attendere alcuni secondi fino allo spegnimento del LED a conferma del corretto apprendimento del codice.
- 11 - Attivare ora la procedura per inserire il nuovo radiocomando sul ricevitore.

NELLA RADIO-RICEVENTE

Verificare il corretto funzionamento del nuovo radiocomando **CARTY-R** vedi **BFT: MODE FAST**

DUPLICARE RADIOCOMANDI ROLLING V2 CON IL CODICE SORGENTE

V2

- 5 - Premere e mantenere premuto il pulsante da copiare del radiocomando originale, fino a che il LED del **CARTY-R** si accenderà fisso.
- 6 - Rilasciare il pulsante ed attendere.
- 7 - Il LED del **CARTY-R** poco dopo emetterà un lampeggio breve circa ogni 2".
Questo avverte l'operatore che è necessario emettere il codice sorgente.
- 8 - Premere contemporaneamente i pulsanti 1 e 2 del radiocomando **V2** e rilasciarli
- 9 - Il LED del **CARTY-R** ora lampeggerà più veloce.
- 10 - Premere e mantener premuto il pulsante del **CARTY-R** sul quale si desidera inserire il codice appena appreso ed attendere alcuni secondi fino allo spegnimento del LED a conferma del corretto apprendimento del codice.
- 11 - Attivare ora la procedura per inserire il nuovo radiocomando sul ricevitore.

NELLA RADIO-RICEVENTE

Verificare il corretto funzionamento del nuovo radiocomando **CARTY-R** vedi **V2: MODE FAST**



Fotografare il QR per entrare nel sito dedicato al radiocomando **CARTY-R**

!!! Se il LED lampeggia solo 3 volte e si spegne il codice non è stato appreso, ripetere l'operazione dal punto 2.

!!! La memoria del **CARTY-R** è completamente riscrivibile.

!!! Per programmare ulteriori pulsanti del **CARTY-R**, ripetere l'operazione dal punto 2.

CONFORMITY DECLARATION		CARATTERISTICHE TECNICHE	
Declare under our sole responsibility that the product EB Technology CARTY-R to which this declaration relates is in conformity with all the essential requirements of the European Directive 2014/53/UE (RED) and the Council Recommendation 1999/15/EC (Human Exposure). The conformity with the essential requirements of the above Regulations has been verified against the following harmonised standards: EN 300 220-2 • EN 301 488-1 • EN 301 489-3 • EN 60950-1-2006 • A11:2009+A1:2010+A12:2011 • EN 50371:2002		Alimentazione:	batteria 3V CR2032
		Portata:	da 60 a 100 mt.
		Frequenze zona UE:	433,92Mhz e 868,30Mhz
IT_CARTY-R	291118_VXX04	www.ebtechnology.it	www.nologo.info

NOLOGO

Compatible remote control, code remote control.

CARTY-R

CLONE THE FIX AND ROLLING CODE WITHOUT THE SOURCE CODE

INITIALIZING

- 1 - Place the original remote control X in front of **CARTY-R** at 4 cm of distance

2 - Press and keep pressed button **1** the LED is **green**

3 - Press **four** times the button **2** and the led will be **red**

4 - Release all buttons

Red LED flashes shortly every 2,5 sec. (8 flashes) for maximum 20sec. **which.....**

CLONE THE FIX AND ROLLING CODE WITHOUT THE SOURCE CODE

All rolling code remote or fix code in the list which can be downloaded in the web site, excluding the remote controls with the source code, see next paragraph.

- 5 - Press and release the button to be copied in the remote and wait for a while until the led **CARTY-R** is flashing quickly to confirm the correct learning copy process.
- 6 - While the LED flashes (max 20sec.), press and keep press the corresponding button on **CARTY-R** where you need to copy the original code until the LED switched off to confirm the right learning copy process.

IN THE RADIO RECEIVER

Choose "**MODE**" in the table: **MODE FAST** or **MODE ENTER** or **MODE MANUAL**

CLONE THE ROLLING FAAC / GENIUS WITH THE SOURCE CODE

FAAC 433 / 868 **GENIUS** 433 / 868

The remote control must be a MASTER, if you press the button the LED flashes twice instead fix light.

- 5 - Press and keep pressed the button to be copied until the Led of **CARTY-R** lits on.
- 6 - Release the button and wait.
- 7 - LED of **CARTY-R** flashes shortly each 2sec.
*This indicate that it is time to memorize the **source code**.*
- 8 - Press simultaneously buttons 1 and 2 of FAAC or GENIUS remote control and release them
- 9 - LED of the remote control FAAC or GENIUS flashes (max 9sec.)
- 10 - Press and keep pressed the button to be copied of FAAC or GENIUS remote control and wait for a few seconds until the LED **CARTY-R** flashes quickly.
- 11 - Press the button which need to be copied and keep pressed until the LED of **CARTY-R** switched off.

IN THE RADIO RECEIVER

Check the right function of the new remote control **CARTY-R**

See **MODE FAST** or **MODE ENTER** pressing twice the memorized button.

NOLOGO

REMOTE CONTROL CARTY-R

CLONE REMOTE CONTROL ROLLING BFT WITH SOURCE CODE BFT

BFT

- 5 - Press and keep pressed the corresponding button of original remote control until the LED **CARTY-R** will lit on
- 6 - Release the button and wait.
- 7 - After a while LED of **CARTY-R** then it will flash every 2 seconds.
*This indicate that it is necessary to put a **source code***
- 8 - Press at the same time buttons 1 and 2 (or push with a pin the hidden button in the back side) of **BFT** remote control and release until the LED **BFT** will turn on.
- 9 - LED **CARTY-R** flashes quickly
- 10 - Press and keep pressed the button **CARTY-R** where you need to memorize the code and wait for a few seconds until the LED switched off to confirm that the code has been successfully copied
- 11 - Activate learning process in the receiver

IN THE RADIO RECEIVER

Check the correct operation of the new **CARTY-R** see **BFT: MODE FAST**

CLONE REMOTE CONTROL ROLLING V2 WITH SOURCE CODE V2

V2

- 5 - Press and keep pressed the corresponding button on original remote control until the LED **CARTY-R** will lit on
- 6 - Release the button and wait.
- 7 - LED of **CARTY-R** will flash shortly for 2 seconds
*This indicate the **source code** is required*
- 8 - Press simultaneously buttons 1 and 2 of **V2** remote control and release them both
- 9 - LED of **CARTY-R** will flash quickly
- 10 - Press and keep pressed the button **CARTY-R** where you need to memorize the code and wait for a few seconds until the LED turned off to confirm the correct copy process.
- 11 - Activate learning process in the receiver

IN THE RADIO RECEIVER

Check if the new **CARTY-R** is working see **V2: MODE FAST**



Scan QR to download info about the **CARTY-R**

!!! If the LED flashes three times and switched off, it means that the code has not been memorized, repeat from step n°2.

!!! The memory **CARTY-R** is completely rewritable.

!!! To memorize more buttons **CARTY-R**, repeat the operation from step n°2.

CONFORMITY DECLARATION		TECHNICAL DETAILS	
Declare under our sole responsibility that the product EB Technology CARTY-R to which this declaration relates is in conformity with all the essential requirements of the European Directive 2014/53/UE (RED) and the Council Recommendation 1999/15/EC (Human Exposure). The conformity with the essential requirements of the above Regulations has been verified against the following harmonised standards: EN 300 220-2 • EN 301 488-1 • EN 301 489-3 • EN 60950-1-2006 • A11:2009+A1:2010+A12:2011 • EN 50371:2002		Power supply:	batteria 3V CR2032
		Range up:	from 60 to 100 mt.
		UE Frequencies:	433,92Mhz / 868,30Mhz
GB_CARTY-R	171218_VXX01	www.ebtechnology.it	www.nologo.info

